

### Ordering information

#### ZV Series

##### ZV 40 K 20 R LI YY

- ZV** - Series Name  
**40** - Maximum Continuous Working Voltage -  $V_{rms}$   
**K** -  $V_n$  Tolerance :  $K = \pm 10\%$ ,  $L = \pm 15\%$ ,  $M = \pm 20\%$   
**20** - Size : 5, 7, 10, 14, 20  
**R** - Packaging : R = Reel, A = Ammo Pack, B = Bulk  
**LI** - Lead Style : 1 = straight, 5 = crimped  
**YY** - Special requirements

#### AV Series

##### AV 20 K 802 006 R LI YY

- AV** - Series Name  
**20** - Maximum Continuous Working Voltage -  $V_{rms}$   
**K** -  $V_n$  Tolerance :  $K = \pm 10\%$ ,  $S = special$   
**80** - Size - 60, 80, 90, 110 : 80 = 8 mm  
**2** - Lead spacing Code : 2 = 5 mm, 3 = 7.5 mm  
**006** - WLD - Load Dump Energy Code : 006 = 6 J  
**R** - Packaging : R = Reel, A = Ammo Pack, B = Bulk  
**LI** - Lead Style : 1 = straight, 5 = crimped  
**YY** - Special requirements

#### CV / CV+ / SV Series

##### CV 130 K 14 R LI YY

- CV** - Series Name : CV, CV+, SV  
**130** - Maximum Continuous Working Voltage -  $V_{rms}$   
**K** -  $V_n$  Tolerance :  $K = \pm 10\%$ ,  $J = \pm 5\%$ ,  $S = special$   
**14** - Size : 5, 7, 10, 14, 20, 23  
**R** - Packaging : R = Reel, A = Ammo Pack, B = Bulk  
**LI** - Lead Style : 1 = straight, 5 = crimped, M = met.,....  
**YY** - Special requirements

### Varistor Marking

#### For Model Size 5, 7

14Z5

- 14** -  $V_{rms}$   
**Z** - the first letter of Series Name ZV  
**5** - Model Size : 5, 7

#### For Model Size 602

20A  
003

- 20** -  $V_{rms}$   
**A** - the first letter of Series Name AV  
**003** - WLD Code : 003

#### For Model Size 5

CV  
130K5

- CV** - Series Name  
**130** -  $V_{rms}$   
**K** -  $V_n$  Tolerance  
**5** - Model Size : 5

#### For Model Size 10, 14

ZV 40  
K 10

- ZV** - Series Name  
**40** -  $V_{rms}$   
**K** -  $V_n$  Tolerance  
**10** - Model Size : 10, 14

#### For Model Size 802

AV 17  
K 006

- AV** - Series Name  
**17** -  $V_{rms}$   
**K** -  $V_n$  Tolerance  
**006** - WLD Code : 006

#### For Model Size 20

KEKO  
ZV 11  
K 20

- KEKO** - Tradename  
**ZV** - Series Name  
**11** -  $V_{rms}$   
**K** -  $V_n$  Tolerance  
**20** - Model Size : 20

#### For Model Size 902, 1103, 20, 40

KEKO  
AV 30  
K 100

- KEKO** - Tradename  
**AV** - Series Name  
**30** -  $V_{rms}$   
**K** -  $V_n$  Tolerance  
**100** - WLD Code : 012, 025, 050, 100

#### For Model Size 7, 10, 14, 20, 23

KEKO  
CV 300 K 20  
xx

- KEKO** - Tradename  
**CV** - Series Name : CV, CV+, SV  
**300** -  $V_{rms}$   
**K** -  $V_n$  Tolerance  
**20** - Model Size : 7, 10, 14, 20, 23  
**xx** - Approvals